

Taal: Engels



Handleiding

CAV

CA NPB 1

CA NPB 2

CA NPB 3

CA NPB 4

CA NPB 5

MSH equipment

Appelmarkt 7

1681 PE Zwaagdijk-Oost

Tel: 0228-561100

Fax: 0228-561112

Mail: info@msh-equipment.nl

Website: www.msh-equipment.nl



CONTENTS

1 GENERAL INFORMATION	3		
1.1 MANUFACTURER	3	4.6.2 ELECTRIC CONNECTIONS	12-13
1.2 POINTS OF SALE AND SERVICE CENTRES	3	4.6.3 SUCTION	14
1.3 CERTIFICATES	3	4.6.4 INSTALLATION COMPLETION	14
1.4 WARRANTY	3	4.7 PRELIMINARY INSPECTION	14
1.5 CUSTOMER'S OBLIGATIONS	3	4.8 ADJUSTMENTS AND CHECKS	14
1.6 MANUAL LAYOUT	4	5 OPERATION	15
1.6.1 PURPOSE AND CONTENTS	4	5.1 PERSONNEL	15
1.6.2 MANUAL ADDRESSEES	4	5.2 CONTROL PANEL	15
1.6.3 MANUAL STORAGE	4	5.3 COMMISSIONING AND USE	15
1.6.4 SYMBOLS	4	5.4 OPERATING MODES	16-17
		5.5 JOB END	18
		5.6 DECOMMISSIONING	18
2 MACHINE DESCRIPTION	5	6 MAINTENANCE	18
2.1 PRINCIPLE OF OPERATION	5	6.1 MACHINE CUT-OFF	18
2.2 MAIN COMPONENTS	5	6.2 SPECIAL PRECAUTIONS	18
2.3 MACHINE STRUCTURE	5	6.3 PARTS SUBJECT TO MAINTENANCE	19-20
2.4 DIMENSIONS	5	6.4 CLEANING 21	
2.5 AMBIENT CONDITIONS	5	6.5 ROUTINE MAINTENANCE	21
2.6 LIGHTING	5	6.6 EXTRAORDINARY MAINTENANCE	21
2.7 VIBRATIONS	5		
2.8 NOISE EMISSIONS	5	7 DIAGNOSTICS	22
2.9 SPECIFICATIONS	6	7.1 TROUBLESHOOTING	22
2.10 OUTFIT	6	7.2 AFTER-SALES SERVICE	23
2.10.1 STANDARD	6		
2.10.2 OPTION EQUIPMENT ON REQUEST	6	8 SPARE PARTS	23
2.11 ELECTROMAGNETIC ENVIRONMENT	6	8.1 SPARE PARTS LIST	23
		8.2 ORDERING SPARE PARTS	24
3 SAFETY RULES	7	9 SCRAPPING	24
3.1 GENERAL WARNINGS	7	9.1 DISPOSING OF WASTE	24
3.2 INTENDED USE	7	9.2 MACHINE SCRAPPING	24
3.3 UNSUITABLE USE	7		
3.4 DANGEROUS AREAS	7	10 ANNEXES	24
3.5 SAFETY DEVICES	7	10.1 DECLARATIONS	27
3.6 STOP CONTROLS	8	10.2 DIAGRAMS	25-26
3.7 SAFE WORKING PROCEDURES	8	10.3 WARRANTY FORM	28
3.8 RESIDUAL RISKS	8	10.4 MAINTENANCE LOG BOOK	29
3.9 NAMEPLATES	8		
4 INSTALLATION	9		
4.1 TRANSPORT AND HANDLING	9		
4.2 STORAGE	9		
4.3 ARRANGEMENTS BEFORE INSTALLATION	9		
4.4 ASSEMBLY	10		
4.5 SET-UP	10		
4.5.1 OPENING THE TOP DOOR	10		
4.5.2 FASTENING THE MACHINE TO THE WALL	10		
4.5.3 FASTENING THE TUBE HOLDER TO THE WALL	11		
4.5.4 CUTTING THE PAINTED ALUMINIUM PIPE	11		
4.5.5 FITTING TUBES AND CABLES	11		
4.5.6 FASTENING THE ALUMINIUM PIPE	11		
4.5.7 CLOSING BACK ALL DOORS	11		
4.6 CONNECTIONS	12		
4.6.1 PNEUMATIC CONNECTIONS	12		



1 GENERAL INFORMATION

1.1 MANUFACTURER

CAV S.r.l. has been manufacturing Supply modules for industrial use for more than thirty years; this experience has led to a considerable technological Know-how based on many years of R&D activities carried out in tight connection with the product manufacturing and trading on the international market, and this is the best quality guarantee that CAV can offer to users.

1.2 POINTS OF SALE AND SERVICE CENTRES

CAV directly offers after-sales service for its products sold in Italy or in Europe.
(Sales, After-sales, Spare parts)

CAV S.r.l.,
Via Morandi, 90 - Toscanella di Dozza (Bologna), Italy
Postal Code 40060
Phone +39 (0)542 673488
E-mail: sales@cavitaly.com

Customers are kindly requested to contact the above-indicated central After-sales Service for any doubt or clarification about use, maintenance or request for spare parts. Please remember to specify the Machine identification details that can be found on the nameplates:
See Nameplate A, paragraph 3.9

1.3 CERTIFICATION

The Machine complies with the prevailing European Union Directives applicable at the moment of its release on the market, as detailed in the declaration of conformity.

1.4 WARRANTY

Machine components are covered by a 12-month (twelve month) warranty: this period starts from the date indicated on the purchase document (invoice). **Warranty does not cover electrical and electronic parts.**

Warranty only covers faulty parts, no labour costs and service call fee.

Warranty excludes any machine damage due to:

- transport and/or handling;
- wrong or improper use of the Machine;
- failed compliance with maintenance specifications given in this Manual; (see paragraph 6.5)
- failures and/or faults not ascribable to faulty parts.

1.5 CUSTOMER'S OBLIGATIONS

The Customer shall, within the time frame agreed upon with the Manufacturer, fulfil its obligations indicated in the Documents attached to the sales contract. Unless otherwise agreed, the Customer normally shall take care of:

- Preparing the rooms, including any required building works and/or channels.
- Air supply with compressed air (see paragraph 4.6.1).
- Machine Power Supply, complying with the prevailing rules in the Country of use (see paragraph 4.6.2).



1.6 MANUAL LAYOUT

The Customer is required to carefully read this manual since correct pre-setting, installation and use of the Machine are basic requirements for its trouble-free and safe operation.

1.6. 1 PURPOSE AND CONTENTS

This manual shall give all necessary information for correct and safe use of the product. It deals with technical information, operation and maintenance details, as well as instructions for spare parts and safety warnings. Before attempting any operation on the machine, operators and qualified technicians are required to carefully read the instructions given herein.

Manual content derives from an ongoing and methodical job of data processing and technical tests filed and approved by C.A.V., complying with the internal safety procedures and data quality rules.

Data herein indicated are **EXCLUSIVELY** for specialised personnel, that could interface with the product under safety conditions for any person, the machine and the environment, carry out a simple troubleshooting and understand strange/faulty operating conditions, carry out simple inspections and maintenance, still fully complying with the instructions given in the following pages and prevailing health and safety regulations.

All details about installation, assembly, removal, extraordinary maintenance, repair and installation procedures for any accessories, devices and equipment, are mentioned and can only be performed by specialised personnel or by the **AUTHORISED AFTER-SALES SERVICE**, fully complying with the manufacturer's recommendations and the prevailing health and safety rules.

It is important to keep this manual in a known place and ensure it is legible, for possible future reference. In case of damage or for further technical and operation details, please contact directly our **AUTHORISED AFTER-SALES SERVICE**.







1. 6. 2 MANUAL ADDRESSEES

This Manual addresses both the operator and the technicians allowed to carry out maintenance operations on the machine. Operators shall not carry out any operation reserved to Maintainers or Qualified Technicians. Failure to do so, the Manufacturer will not be liable for any resulting damage.

1.6.3 MANUAL STORAGE

This Manual shall be kept next to the Machine and in such a position protected from any fluid or any other condition that could compromise its readability.

1.6.4 SYMBOLS

	DANGER	Indicates a hazard resulting in a (serious) risk for user or any other person.
	WARNING	Pay utmost attention to the paragraphs highlighted by this symbol.
	DANGER OF ELECTROCUTION	Indicates a hazard resulting in a (serious) risk for user or any other person.
	SPECIALISED PERSONNEL	Specialised personnel is required for special operations.
	SEE MANUAL	It is necessary to refer to the User's Manual before attempting a certain operation.
	ADJUST	Mechanical adjustment and/or electric set-up could be necessary.



2 MACHINE DESCRIPTION

2.1 PRINCIPLE OF OPERATION

The supply modules are utility organs making available all utilities required for factory works: suction, power supply and compressed air. They are terminals able to meet the most diverse needs of the final user.

The supply modules are also equipped with 230V and 400V power sockets and can support one or two operators.

They are wall-mounted.

2.2 MAIN COMPONENTS

The supply modules consist of the following main components:

- air regulators
- pressure gauges
- safety quick cock for direct compressed air
- safety quick cocks for regulated compressed air
- manual air locks
- power sockets
- two shelves for storing small tools

2.3 MACHINE STRUCTURE

Unit bedplate and main parts are made of a stiff steel structure. Pressure regulators and safety quick cocks for compressed air feed are installed at the front. Two power sockets are equally available at the front. While two suction openings are available at the bottom.

Power supply connections are realised by means of a simplified connector system.

2.4 DIMENSIONS

Overall dimensions are specified under paragraph 2.9 -Specifications.

2.5 AMBIENT CONDITIONS

The machine does not require any special ambient conditions. Nevertheless, it shall be installed in a well-lit and ventilated industrial building.

Ambient temperature for correct unit operation shall be in the range +5°C to +40° C.

2.6 LIGHTING

Room lighting shall comply with the prevailing rules in the country where the machine is installed and shall at any rate ensure good visibility through the whole work area. Minimum recommended illumination: 400 lux.

2.7 VIBRATIONS

If unit is used according to the instructions for correct use, vibrations shall not create any dangerous situation.

2.8 NOISE EMISSIONS

The machine is designed and manufactured to limit noise emissions at the source.

The product is not noisy per se.

Noise emissions shall be measured according to used equipment.



2.9 SPECIFICATIONS

This section indicates Machine technical features and specifications user shall refer to in case of contact with the Manufacturer After-sales Service.

TABLE 2. 9A - Technical Features and Specifications

Description	Features
Interlocked power socket	NPB1: 2x230V 16A NPB2: 1x230V 16A + 1x400V 16A NPB3: 1x230V 16A + 1x400V 16A 5 pin NPB4: 1x230V 16A + 1x400V 32A NPB5: 1x230V 16A + 1x400V 32A 5 pin
Compressed air regulator	2x 0-8 bar 3/8"
Suction opening	Ø45mm
Dimensions (mm)	664x301x1950(H) (mm)
Weight (kg)	25 kg

2.10 OUTFIT

The following equipment refers to the standard production machines. Any special machine could hence require parts different than the listed ones.

2.10.1 STANDARD

The machine comes with:

- User's Manual
- Declaration of conformity

2.10.2 OPTION EQUIPMENT ON REQUEST

No options are set with respect to the standard outfit.

Any change and/or addition of any accessory whatsoever must be explicitly approved and made by the Manufacturer.

2.11 ELECTROMAGNETIC ENVIRONMENT

The machine is designed to operate correctly within an electromagnetic or industrial environment. Design conforms to the principles of the product Harmonised Technical Standards:

HARMONISED EUROPEAN STANDARD EN 60439-1(third edition)
February (1995) ref. CENELEC EN 60439-1:1994-01

HARMONISED EUROPEAN STANDARD EN 60439-1/AI/AII
September (1997) ref. CENELEC EN 60439-1/AI:1995-12+ EN 60439-1/AII:1996-02
In particular, manufacturer used proven components and principles, as required by 7.10 of EN 60439-1/AI:1995-12+ EN 60439-1/AII:1996-02

Built-in electronic equipment was installed as indicated in the instructions that come with the equipment itself and considering the general criteria for **EMC** specified in **EN 60204-1**.



3 SAFETY RULES

3.1 GENERAL WARNINGS

The Operator shall carefully read the information given in this Manual, especially the Safety rules and precautions specified in this section.

Moreover, it is fundamental that the Operator follows these warnings:

- keep the machine and the work area clean and in order;
- use the machine in normal psychophysical conditions;
- wear appropriate clothes and personal protection gear suitable for products in use;
- do not remove or tamper with the Manufacturer nameplates on machine;
- do not remove or make inoperative any of the machine Safety systems.
- **Do not use this unit in rooms subject to risk of explosion.**

3.2 INTENDED USE

The machine is designed for removing non-explosive dust in general or similar material.

3.3 UNSUITABLE USE

The machine shall not be used:

- for different purposes than those indicated in 3.2;
- to take in substances that could result in a flammable and/or explosive environment;
- in environments featuring explosive, aggressive atmosphere or with high dust or oily content;
- in environments with a serious fire hazard;
- outdoors, exposed to any weather condition;
- to take in red-hot parts and/or parts on fire;
- in a different way than stated in safety installation rules given herein.

3.4 DANGEROUS AREAS

Although the machine does not involve any particular danger for exposed persons, it shall be used taking some precautions, considering that:

- the operator can come into contact with dangerous chemical products by accident and without being aware of the resulting danger.
- Before use, the person in charge of production shall evaluate unit use conditions according to the danger possibly caused by products and take suitable protections such as: work in a room featuring a guaranteed minimum ventilation or change of air.

3.5 SAFETY DEVICES

The machine comes complete with suitable guards to protect the persons exposed to risks due to moving organs, bursting of pressurised air tubes, risks connected to power supply, and so on.

The unit fits the following safety devices:

- disconnecting lever on power socket to release socket only once cut-out has tripped.

The User is requested to install the following safety devices:

- **Electrical equipment with TT system:** automatic circuit breaker with differential protection against direct and indirect contacts on machine power control panel (if activated, it causes uncontrolled stop of all actuators and power cut-off);
- **Electrical equipment with TN or IT system:** refer to sockets specifications to install the suitable protections.



3.6 STOP CONTROLS

The machine stop controls are:

- Main Switch (to set unit out of service, located on control panel installed by the Customer);
- disconnecting lever on power socket to release socket only once cut-out has tripped.

3.7 SAFE WORKING PROCEDURES

The machine design features aim at eliminating all risks connected to its use.

The residual risks involved in manual operating mode are:

- risks connected with the use of pneumatic energy;
- risks connected with the use of electric energy;
- risks of possible contact with product removed by suction.

To limit the consequences of such dangers as much as possible, it is important to comply with the following rules:

- Ensure that air supply pressure is available and set to specified value: **max. 10 bars**;
- Do not start the machine before checking the correct installation and operation of set parameters; this can be done by running a cycle with no product to be taken in by exhauster;
- Wear the personal protection gear suitable for the product in use;
- Wear clothes with close-fitting sleeves.


3.8 RESIDUAL RISKS

During the normal suction cycle and during maintenance, the Operators can run some residual risks that can not be completely avoided, due to the type of operation being performed, such as danger of electrocution.

3.9 NAMEPLATES

Table 3. 9A - Types of Nameplates

Nameplates on the machine - fig.3.9.A




Nameplate "B"



Nameplate "C"



Figure 3. 9 B - Nameplates position



	WARNING! THE SAFETY WARNING NAMEPLATES SHALL NOT BE REMOVED, COVERED OR DAMAGED
--	---

4 INSTALLATION

4. 1 TRANSPORT AND HANDLING

Have unit transported by qualified and trained Personnel. The machine shall be handled in a suitable way so as to avoid damages. All protections, electric circuits, control equipment, shall be suitably closed and fastened.

The machine is packed wrapped in plastic and covered with cardboard. Packed machine dimensions and weight are indicated on the package. Check for transport damages together with the carrier.

N.B.: The Manufacturer will not be liable for damages due to improper lifting and handling of the packed unit.

	WARRANTY does not cover any damage to the machine due to transport and handling. Any repair or replacement of damaged parts is at the Customer's charge.
--	---

4. 2 STORAGE

For any long period of inactivity, store the machine in a suitable place, considering storage environment and time. In particular, consider allowed temperature range, humidity and pollution.

- Store the machine indoors;
- Protect the machine from any shock and stress;
- Protect the machine from humidity and extremely wide temperature ranges +0° C + 60 °C;
- Avoid contact with corrosive substances.

4.3 ARRANGEMENTS BEFORE INSTALLATION

Before installation, it is necessary to prepare a suitable operating area, limiting any interference with other activities as much as possible.



4.4 ASSEMBLY

Machine can be assembled either by the technicians authorised by the manufacturer or directly by the customer, following these steps:

Unpacking.

Remove all packing material from the machine, using suitable tools and setting it in a suitable place. Dispose of the packing material according to the prevailing environment protection regulations.

(Visually) **check** machine external parts for damage, carefully ensure that there are no scratches, denting or damaged parts.

Report any fault, failure or missing parts found within five days from machine arrival. Beyond this term the Manufacturer is no longer liable for the machine supplied.

WARNINGS AND PRECAUTIONS for installation

Always start by checking correct operation, assembly and efficiency of controls and safety systems. **In case** you find operating faults, immediately stop the machine and contact the AUTHORISED AFTER-SALES SERVICE. **Pay attention** to the adhesive nameplates on the machine. Should they become damaged or illegible, promptly change them. For this operation contact the AUTHORISED AFTER-SALES SERVICE or the Manufacturer. Have **any maintenance intervention** -as per the definition of "user" given in the foreword section- performed by qualified personnel. **Using spare parts** that do not comply with the following specifications, any change or tampering (though small as they may be) relieve the Manufacturer of any liability concerning the correct use, operation and safety of persons and/or property. **It is strictly forbidden** to tamper with equipment, control organs and safety devices. **Dispose of waste** as required by the prevailing laws. **If the machine** is used by many operators, all of them shall read the instructions for use and indicate any maintenance intervention or parts replaced, or just suspected faults, on the servicing data sheet.

4.5 SET-UP

Instructions below refer to machine wall mounting. Two operators are required to carry out all operations from this point until installation is completed.

4.5.1 OPENING THE TOP DOOR

Remove the blanking plugs and loosen the two bolts securing the top door in place.


Warning: pay special attention in this stage since machine is not balanced!

4.5.2 FASTENING THE MACHINE TO THE WALL

Fix the machine to the wall (or suitable support) using the four mounting holes (A) on rear bracket, and make sure it is perfectly vertical.

You need to open the doors to carry out this step.


Warning: pay special attention in this stage since machine is not balanced!





4.5.3 FASTENING THE TUBE HOLDER COLLAR TO THE WALL

Fasten the tube holder collar to the wall, at the same height as the machine top union.



4.5.4 CUTTING THE PAINTED ALUMINIUM PIPE

The painted aluminium pipe shall be cut to the desired length.

4.5.5 INSERTING PIPES AND CABLES INSIDE THE ALUMINIUM PIPE.



4.5.6 FASTENING THE ALUMINIUM PIPE USING THE TUBE HOLDER COLLAR.

4.5.7 CLOSING BACK ALL DOORS AND FASTENING THE TOP DOOR.





4.6 CONNECTIONS

To avoid any problem upon machine start-up, follow the instructions below.

4.6.1 PNEUMATIC CONNECTIONS

Figure 4. 6. 1A- Pneumatic System Layout (A)

Connection to the air supply is ensured by a flexible hose having an inner diameter of 10mm.


The mobile connection is supplied together with the machine.

Air supply requirements:

- Operating pressure: 6 bars
- Maximum pressure: 10 bars

Connect compressed air supply to the 10x15 tube, by inserting a gate valve or air lock (to be supplied by Customer) on the pre-set line so that the supply can be cut off during maintenance. It is strongly recommended to feed the machine with dry compressed air.

Compressed air of the supply line must be completely dry, i.e. treated upstream of the exhauster. It is recommended to install a 5 micron air filter upstream.



4.6.2 ELECTRIC CONNECTIONS


Figure 4. 6. 3A- Electrical System Layout (B)

POWER SUPPLY

Machine electrical connections are at the Customer's charge, under its own responsibility.

The electrical connections of the machine shall consider:

- the Laws and Technical standards applicable at the time of installation in the place of installation
- data indicated on " Nameplate A "







Make the electrical connections. Supply power to the power sockets connector with a separate line of suitable cross-section, also providing suitable protections for direct and indirect contact. Tighten the cable glands on power sockets once all connections are done. **This line and the relevant protections are at the Customer's charge.**

The two-wire cable shall be connected to the signal line at exhauster input (at the Customer's charge).

The electrical system design and components ensure utmost dependability and safety of use. The attached wiring diagrams will allow identification of all connections and components. Only make the required electrical connections; do not modify any circuits, calibrations, components, etc. Failure to follow this warning will be considered as tampering. Before connecting to the mains, ensure that power voltage and frequency correspond to the specifications indicated on the nameplate. **Perform ground connections and/or zero setting as required by the prevailing laws of the country.**



Emergency knife switch



Control unit power sockets

Signal cable connector





4.6.3 SUCTION

Connect the dust suction tube to suction central line. “Peel” the copper wire and fold it inward (if tube is grounded) or connect it to a ground or bonding lead.



4.6.4 INSTALLATION COMPLETION



4.7 PRELIMINARY INSPECTION

Power supply, Compressed Air supply and machine preparation stages for Commissioning do not require any special knowledge apart from that acquired after reading this manual.

Before starting up the Machine it is necessary to perform some inspections and checks in order to avoid errors or accidents:

- ensure that the machine did not suffer any damage during assembly;
- pay special attention when checking electrical parts, cables and air lines;
- check that all external supplies connections are correct;
- ensure that all mobile parts can move freely.

4.8 ADJUSTMENTS AND CHECKS

The machine is tested at the Manufacturer's premises, before shipment. No further adjustment is necessary.

When starting the machine for the first time, proceed as follows:

- set the Main switch QSI lever to ON (switch is installed by the Customer);
- open compressed air supply cock.



5 OPERATION

5.1 PERSONNEL

The machine is designed for use by one or two Operators.

Personnel allowed to work on the machine shall have the following knowledge (or acquire it after suitable training) and be familiar with the contents of this Manual as well as all Safety-related concerns:

General and technical knowledge of suitable level to understand Manual contents;

- Knowledge of the main health and safety and accident prevention rules;
- Knowledge of how to behave in an emergency situation, where to find personal protection gear and how to use it correctly.
- Maintainers, apart from the above, shall also have suitable electrical, pneumatic and mechanical Technical knowledge.


5.2 CONTROL PANEL

Machine controls are on the front control panel.

Figure 5. 2.B - **Controls and Pneumatic inspections**

Pneumatic sys.key:

1. Pressure regulator.
2. Pressure gauge.
3. Quick cock for regulated compressed air.
4. Quick cock for direct compressed air.
5. Power sockets switches



5.3 COMMISSIONING AND USE

To power on the machine, proceed as follows:

1. set the Main Switch to ON
2. open compressed air supply cock.



5.4 OPERATING MODES

After commissioning, you can use the machine in the following Operating Modes:

Off

Manual

Fit the supplied union in the suction opening.

Off Mode

Using this operating mode, the system can supply power and air while suction stays off (e.g. for painting).

Manual mode


By manually working gate valve "A" operator can open the mouthpiece and this outputs a remote contact to switch suction on.

The user can perform required suction work using the sleeve.

To switch suction off, just take gate valve "A" to its original position.

Pressure adjustment

If you try to work the knob and it does not turn (stuck), you shall pull it. Now it is free to turn both ways to increase or decrease pressure output to the sander/spray gun fitting. It is recommended to first set pressure to a value lower than required, then slowly increase it up to required value.





Connecting and disconnecting the compressed air fittings

Connection

Install the fitting inside the safety quick cock until it locks in place. Now you can use compressed air.

Disconnection

It requires two steps:

1st step: Grab cock ring nut and push cock until fitting is released.

2nd step: now, any air present in the tool tube will discharge and you can remove the fitting by pulling the ring nut. With this operation, you release the quick cock mechanical lock and you can withdraw the fitting.

Connection



Disconnection - step 1



Disconnection - step 2





5.5 JOB END

The procedure for a voluntary Stop is as follows:

1. Open the main switch contact on control panel (OFF position);
2. Close compressed air supply cock.

5.6 DECOMMISSIONING

In case of long periods of inactivity or **in case of maintenance, user shall compulsorily:**

- Open and padlock the main switch on main control panel (see Figure 6.1 A);
- Close and lock compressed air inlet valve (see Figure 6.1.B);
- Release circuit air by inserting a fitting in the direct air quick cock
- Put out a panel reading "MACHINE BEING SERVICED".


6 MAINTENANCE

6.1 CONTROL UNIT CUT-OFF


Before attempting any Maintenance or Repair job, user must cut all machine supplies, proceeding as follows:

1. Open and padlock the main switch on main control panel.
2. Close and padlock or disconnect the quick-release coupling to cut off the compressed air supply.

6.1A



6.1B



6.2 SPECIAL PRECAUTIONS

When carrying out maintenance or repair jobs, it is recommended to proceed as follows:

- Before starting, put out a panel reading "MACHINE BEING SERVICED" in a visible position.
- Do not use solvents and flammable materials.
- Do not release lubricants into the environment.
- Machine parts are not designed to bear a person's weight; do not stand on them or they could break.
- When job is completed, restore and correctly fasten all protections and guards previously removed or opened, as well as any safety device, if previously removed.



6.3 PARTS SUBJECT TO MAINTENANCE

Maintenance shall be carried out with the machine set out of service for replacement of damaged or worn parts. The machine does not require frequent maintenance. If compressed air does not meet indicated requirements, the following could get damaged:

1. Pressure regulator

Remove the regulator:


- Close air feed;
- Discharge any residual air;
- Insert a fitting in the quick cock and allow all air to discharge;
- Reset (zero) the regulator by working the knob anticlockwise until it stops.
- Remove the adjuster knob by pulling it;
- Open the regulator by loosening the knob tang.
- Clean or change the membrane then reassemble the unit proceeding in the reverse order.







Shutter

- Close air feed;
- Discharge any residual air;
- Insert a fitting in the quick cock and allow all air to discharge;
- Reset (zero) the regulator by working the knob anticlockwise until it stops;
- Loosen filter-governor cup;
- Loosen filter bottom (A) and remove the filtering element;
- Loosen shutter seat and check for wear or damage (B).
- If necessary, change the shutter seat and reassemble proceeding in the reverse order.



4) Changing the air lock assembly

- Cut off power and air supply (see relevant procedures in the previous pages);
- discharge the air circuit after setting the system in safety conditions;
- remove the two blanking plugs on top door (A);
- loosen the two bolts fastening the top door in place;
- open the top door;
- disconnect suction tube from air lock;
- loosen the gate valve control knob (B);
- remove the whole air lock assembly by loosening the four bolts retaining it to the metal plate;
- on a bench, change any worn (broken) air lock parts;
- reassemble the air lock unit into its seat;
- reconnect the suction tube;
- Close back the top door after performing all required operations.





6.4 CLEANING

It is recommended to frequently clean the whole Machine (intervals depend on type and frequency of use). Use a soft rag. Do not use water and/or solvents.

6.5 ROUTINE MAINTENANCE

The following operations shall be performed at the indicated time intervals. Failure to comply with this schedule will relieve the Manufacturer of any liability or warranty obligation.

These operations, though simple as they may be, shall be carried out by **suitably trained and expert Personnel**.

Scheduled routine maintenance includes inspections, tests and interventions aiming at preventing system stoppage due to faults or potentially dangerous situations.

It is suggested to Clean the equipment weekly in order to guarantee trouble-free operation and long life.

MAINTENANCE	DESCRIPTION	INTERVENTION
Pneumatic System	Valves and tubes/lines	No scheduled maintenance required
Electrical System	Sockets	No scheduled maintenance required
Suction System	Air lock	Change, when required

6.6 EXTRAORDINARY MAINTENANCE

Extraordinary maintenance is an activity reserved to personnel appointed by the manufacturer or the manufacturer itself. Please contact the centres specified under paragraph 1.2 in case of need. **Considering the machine yearly maintenance, the intervention of a technician for extraordinary maintenance is highly unlikely, unless for special cases or when expressly requested.**



7 DIAGNOSTICS

7.1 TROUBLESHOOTING

Table 7.1 A

TROUBLE	CAUSE	INSPECTION AND/OR FIX
The power tool is not working.	<ul style="list-style-type: none">• No power supply from the mains.• Socket fuses blown.	<ul style="list-style-type: none">• Restore power supply from the mains.• Change the fuses.
Exhauster does not turn on	<ul style="list-style-type: none">• Wiring connection error.• Microswitch failure	<ul style="list-style-type: none">• Restore remote contact connection.• Change the microswitch
The pressure regulator puffs.	<ul style="list-style-type: none">• Poor quality compressed air.	<ul style="list-style-type: none">• Remove and clean the regulator.• Install an air filter at inlet.
The air lock baffle plate moves very slowly.	<ul style="list-style-type: none">• Gate baffle plate worn out/damaged.	<ul style="list-style-type: none">• Disassemble the air lock unit and change any worn/damaged parts.



7.2 AFTER-SALES SERVICE

The Manufacturer is always willing to answer Customer's questions and give information on use, maintenance or installation and so on. Please follow the instructions given under paragraph 1.2 on how to request our assistance.

8 SPARE PARTS

8.1 SPARE PARTS LIST

Machine use does not involve any expendable parts. Following is the list of available spare parts.

Table 8.1- A

POS..	DESCRIPTION	Part no.
1	Interlocked power socket 230V 16A	7571
2	Interlocked power socket 400V 16A	7568
	Interlocked power socket 400V 16A 5pin	7577
	Interlocked power socket 400V 32A	7536
	Interlocked power socket 400V 32A 5pin	7538
3	Y-shaped conveyer	NSR-0010
4	Microswitch carrier box	35-6-1008-ANT
5	O-ring	8111
6	Microswitch	9082
7	Gate valve	35-6-1003-ANT
8	Cover	35-6-1009-ANT
9	Filter-governor 3/8"	6709
10	Pressure gauge 0-12 1/8"	K2-78
11	Safety quick cock 3/8"M	6303 green tag 6303-S blue tag
12	Safety quick cock 3/8"F	6304 green tag 6304-S blue tag
13	Pipe support hook	G-2



8.2 ORDERING SPARE PARTS

We remind you that the machine can only be repaired by a qualified technician.

It is hence recommended to contact the Manufacturer After-sales Service that will make available Qualified Personnel, suitable tools and original spare parts.

To order above-listed spare parts, please refer to paragraph 1. 2

9 SCRAPPING

9.1 DISPOSING OF WASTE

During processing, waste or rejections are created that shall be collected, recycled or disposed of, in compliance with the prevailing laws of the country where the Machine is installed.

9.2 MACHINE SCRAPPING

Upon unit scrapping, separate the plastic parts from any electrical components, that shall be sent to different waste disposal centres, as per prevailing rules.

The machine metal parts shall be divided into steel and other metals or alloys, and then routed to recycling firms.

Unit scrapping does not cause any special risk, as far as it is performed by qualified personnel with suitable equipment.

10 ANNEXES

10.1 DECLARATIONS

The following Declarations are hereby attached:

- Declaration of conformity.


10.2 DIAGRAMS

The following Diagrams are hereby attached:


- Electric circuit diagram
- Pneumatic circuit diagram
- Machine exploded view




Electric circuit diagram



Pneumatic circuit diagram





Please, see descriptions in Table 8.1 A - page 23



THE UNDERSIGNED COMPANY **C.A.V SR.L.**

VIA R. MORANDI, 93 - 40060 TOSCANELLA DI DOZZA (BO)
TEL.: +39 0542 673488 - TELEFAX: +39 0542 672065
E-MAIL: SALES@CAVITALY.COM - HTTP://WWW.CAVITALY.COM
M/BO 015576
ITALY

DECLARES, UNDER ITS OWN EXCLUSIVE RESPONSIBILITY, THAT THE MACHINE

MODEL NPB

REGISTRATION NO.

CONSTRUCTION DATE

TO WHICH THIS DECLARATION IS REFERRED, IS IN ACCORDANCE WITH THE FOLLOWING DIRECTIVES:

DIRECTIVE 2006/42/EC (MACHINERY DIRECTIVE)
DIRECTIVE 2006/95/EC (LOW VOLTAGE DIRECTIVE)
DIRECTIVE 2004/108/EC (ELECTROMAGNETIC COMPATIBILITY DIRECTIVE)

FURTHERMORE, WE DECLARE THAT THE TECHNICAL DOSSIER HAS BEEN COMPILED BY:

LUCA LUCIA
C/O C.A.V. SRL
VIA R. MORANDI, 93 - 40060 TOSCANELLA DI DOZZA (BO)
TEL.: +39 0542 673488 - TELEFAX: +39 0542 672065
E-MAIL: UT@CAVITALY.COM

TOSCANELLA,

TECHNICAL DOSSIER COMPILER

LUCA LUCIA

LEGAL REPRESENTATIVE

DOMENICO LUCIA



**Please fill in and return this form by fax
for Warranty registration**

Date:

Machine model:

Serial no.:

Year of manufacture:

To be filled in by the Customer

Company name

Address

Phone no.: Fax no.:

E-mail:

Company name of installing firm

.....
.....



C.A.V. srl

Via R. Morandi, 93 - 40060 Toscanella di Dozza (BO)

Tel.: +39 0542 673488 / Fax: +39 0542 672065

www.cavitaly.com - sales@cavitaly.com

www.smaisystem.com - info@smaisystem.com