


# D-4135 AIR BODY SAW



## PARTS LIST

No.	Parts No.	Description	Q'ty	No.	Parts No.	Description	Q'ty
1	SPD4135F-01	Valve Screw	1	27	SPD4135F-27	Bushing	2
2	SPD4135F-02	O-Ring	1	28	SPD4135F-28	Chuck Cover	1
3	SPD4135F-03	O-Ring	1	29	SPD4135F-29	Set Screw	2
4	SPD4135F-04	Air Controller	1	30	SPD4135F-30	Screw	2
5	SPD4135F-05	Valve Spring	1	31	SPD4135F-31	Housing	1
6	SPD4135F-06	O-Ring	1	32	SPD4135F-32	Housing Cover	1
7	SPD4135F-07	Valve Stem	1	33	SPD4135F-33	Gasket	1
8	SPD4135F-08	O-Ring	1	34	SPD4135F-34	Packing	1
9	SPD4135F-09	Valve Bushing	1	35	SPD4135F-35	Safety Lever	1
10	SPD4135F-10	valve Block	1	36	SPD4135F-36	Hanger	1
11	SPD4135F-11	Lcok Washer	4	37	SPD4135F-37	Spring Pin	1
12	SPD4135F-12	Cap Screw	4	38	SPD4135F-38	Front Bumper	1
13	SPD4135F-13	Stop Ring	1	39	SPD4135F-39	Set Screw	1
14	SPD4135F-14	Air Hose Ass'y 1/4"	1	40	SPD4135F-40	Piston Ass'y	1
15	SPD4135F-15	Sponge	1	44	SPD4135F-44	Rear Bumper	1
16	SPD4135F-16	Exhaust Hose	1	45	SPD4135F-45	Packing	1
17	SPD4135F-17	Work Guide	1	46	SPD4135F-46	Cylinder	1
18	SPD4135F-18	Blade	2	47	SPD4135F-47	Packing	1
19	SPD4135F-19	Set Screw	2	48	SPD4135F-48	Bushing	1
20	SPD4135F-20	Blade Chuck	1	49	SPD4135F-49	Valve Case	1
21	SPD4135F-21	Spring	1	50	SPD4135F-50	Valve Sleeve	1
22	SPD4135F-22	Cap Screw	2	51	SPD4135F-51	Actuate Valve	1
23	SPD4135F-23	Bridge	1	52	SPD4135F-52	Washer	1
24	SPD4135F-24	Blade Guide	2	53	SPD4135F-53	Screw	1
25	SPD4135F-25	Upper Wear Shoe	1	54	SPD4135F-54	Service Wrench (2mm)	1
26	SPD4135F-26	Guide Plate	1	55	SPD4135F-55	Service Wrench (4mm)	1